



# TMC256xH Manual

---

TMC256BH / TMC256EH



Revision

| Version | Date        | Contents                       |
|---------|-------------|--------------------------------|
| 1.0     | JUN.27.2024 | 1 <sup>st</sup> Release        |
| 1.1     | FEB.06.2026 | Detailed specifications update |
|         |             |                                |
|         |             |                                |
|         |             |                                |
|         |             |                                |
|         |             |                                |
|         |             |                                |
|         |             |                                |
|         |             |                                |


## Chapter

|  |    |
|--|----|
| 1. Introduction.....                                     | 3  |
| 1.1.    Figure.....                                      | 3  |
| 1.2.    Key Features.....                                | 3  |
| 2. Specifications .....                                  | 4  |
| 3. Installation .....                                    | 5  |
| 2.1.    Ethernet.....                                    | 5  |
| 2.2.    USB .....  | 6  |
| 4. Mechanical Drawings.....                              | 7  |
| 4.1.    Basic Dimension.....                             | 7  |
| 4.2.    Mounting Block Dimension.....                    | 8  |
| 4.3.    Window Dimension .....                           | 9  |
| 5. Maintenance.....                                      | 10 |
| 5.1.    Clean the Case.....                              | 10 |
| 5.2.    Window Care .....                                | 10 |
| 6. Troubleshooting.....                                  | 11 |
| 6.1.    Scan Camera is not working on Remote Camera..... | 11 |
| 7. Support.....  | 12 |
| 8. Glossary .....  | 13 |

## 1. Introduction

The Thermoeye TMC256BH and TMC256EH cameras are compact thermal camera and suitable for application to research and industrial products. They offer comprehensive visual temperature monitoring for process control and quality assurance applications as well as condition monitoring and fire prevention.

### 1.1. Figure



| Item | Description           | Item | Description |
|------|-----------------------|------|-------------|
| ①    | Window                | ③    | USB cable   |
| ②    | Tripod mounting holes | ④    | PoE cable   |



### 1.2. Key Features



- ✓ Resolution : 256 x 192
- ✓ Field of View : 56° x 42° / 90° x 65°
- ✓ Frame Rate : 25Hz
- ✓ Noise Equivalent Temperature Difference : ≤50mK
- ✓ Compact Size : 45mm x 45mm x 45mm (53.5mm/including mounting block)
- ✓ Interface : USB or Ethernet (PoE)



## 2. Specifications

| Model                 |              | TMC256BH   |         |        | TMC256EH  |         |        |
|-----------------------|--------------|--|---------|--------|---|---------|--------|
| Sensor                |              | Uncooled VOx Microbolometer  |         |        |   |         |        |
| Spectral Range        |              | 8μm ~ 14μm   |         |        |   |         |        |
| Resolution            |              | 256 X 192  |         |        |   |         |        |
| Pixel Pitch           |              | 12μm   |         |        |   |         |        |
| NETD                  |              | ≤50mK @25℃   |         |        |   |         |        |
| Frame Rate            |              | 25Hz   |         |        |   |         |        |
| FOV                   |              | 56 ° x 42 ° / 90 ° x 65 °  |         |        |   |         |        |
| Measure Range         | High Gain    | -10℃ ~ 150℃  |         |        |   |         |        |
|                       | Low Gain     | 50℃ ~ 550℃   |         |        |   |         |        |
| Accuracy              | High Gain    | ± 2℃ or ± 2%   |         |        |   |         |        |
|                       | Low Gain     | ± 5℃ or ± 5%   |         |        |   |         |        |
| Interface             |              | USB-HS (Type-A)  |         |        | Ethernet (RJ-45)  |         |        |
| Protocol              |              | UVC, CDC ACM   |         |        | TCP, UDP, RTSP, RTP   |         |        |
| Operating Temperature |              | -10℃ ~ 70℃   |         |        |   |         |        |
| Power                 |              | USB DC5V<br>USB<br> |         |        | PoE(802.3af) DC12V ※<br>DC 12V PoE<br> |         |        |
| Cable Length          |              | 144mm  |         |        | 56mm  |         |        |
| Size                  |              | 45mm x 45mm x 45mm (53.5mm/including mounting block)   |         |        |   |         |        |
| Power Consumption     | State / Unit | Voltage  | Current | Watt   | Voltage   | Current | Watt   |
|                       | Idle         | 5V   | 156mA   | 780mW  | 12V   | 64mA    | 768mW  |
|                       | Streaming    |  | 160mA   | 800mW  |   | 75mA    | 900mW  |
|                       | FFC          |  | 260mA   | 1300mW |   | 110mA   | 1320mW |

※ PoE adapter (PoE switch, injector) and DC12V adapter are not provided.

※ Don't connect the DC12V and PoE adapter at the same time. This may damage the device.

※ If you use a general switch other than PoE, you can use a DC12V for separate power supply.

### 3. Installation

Connect the camera device to a Windows PC via Ethernet or USB cable and check the connection status with the ThermoCamSDK.




Figure 1. System Configuration Diagram

The TmSDK GUI can be downloaded from the Thermoeye Github. For detailed instructions, please refer to the separately provided TmSDK manual.

<https://github.com/thermotye/tmsdk>

#### 2.1. Ethernet

Connect the camera device and a network switch that supports PoE with an RJ-45 Ethernet cable. And the LED will turn on when it boots up normally.

When you run the TmSDK on a PC connected to the network, you can find connectable camera devices on the network and view the device list and product information on the **Remote Camera** tab, as shown below.

Remote Camera Local Camera

Name: TMC256I

Part #: TMC256IEB-T56F1001

Serial #: -----

MAC: -----

IP Address: 192.168.0.150

Adapter IP: 192.168.0.50

Video Format

Y16 : 256x192@25fps-16bpp

Connect

Scan Camera

TMC256I-192.168.0.150

TMC256E-192.168.0.162

TMC384G-192.168.0.180

TMC256E-192.168.0.191

TMC256E-192.168.0.200

The default network settings for your device are:

- IP Assignment: Static
  - IP Address: 192.168.0.150
  - Subnet Mask: 255.255.255.0
  - Gateway: 192.168.0.1
  - Main DNS Server: 164.124.101.2
  - Sub DNS Server: 168.126.63.1
  - Protocol and Port:
- UDP (15000), RTSP/TCP (554), RTP/UDP (50000-51000)

Network settings can be changed on the **Network** tab after connecting with the camera device.

Figure 2. Ethernet Connection

## 2.2. USB

Connect the camera device and a PC with an USB cable.

When you run the TmSDK on your PC, you can find connectable camera devices and view the device list and product information in the **Local Camera** tab, as shown below.





Figure 3. USB Connection

You can also view the connection information in the Windows Device Manager.

USB connection is possible using the product name and COM port number of the camera device.


The COM port number might change each time you connect the camera device with a USB cable.

If you change the display to "View ⇨ Devices by container" from the menu in Device Manager, you can see the USB camera product name and COM port number included with the camera device at a once.




## 4. Mechanical Drawings

### 4.1. Basic Dimension






## 4.2. Mounting Block Dimension



### 4.3. Window Dimension



## 5. Maintenance

Cleaning and window care are the only maintenance required to the product.

### 5.1. Clean the Case

Clean the case with a soft cloth and a weak soap solution.

**Caution!**

**To prevent damage to the case:**

- ✓ Do not use abrasives, isopropyl alcohol, or solvents to clean the case.

### 5.2. Window Care

Use a pressurized can of air or a dry nitrogen-ion gun, if available, to blow off the particulates from the window surface.

Clean the window with a polyester micro fiber fabric cloth.

**Caution!**

**To prevent damage to the window:**


- ✓ Carefully clean the window. The window has a delicate anti-reflective coating.
- ✓ Do not clean the window too vigorously because this can damage the anti-reflective coating.

## 6. Troubleshooting

Please refer to this if you encounter any problems during product installation or SDK development.

### 6.1. Scan Camera is not working on Remote Camera

If you execute Scan Camera to find a Remote Camera connected to PoE on a PC equipped with Wi-Fi wireless adapter, but you cannot find any device, please set all of **Microsoft Wi-Fi Direct Virtual Adapter** devices to **Disable device** on the network adapter in the PC's Device Manager as follows.



## 7. Support

Thermoeeye Inc. operates service channels to keep your camera running at all times. If you discover a problem with your camera, please get in touch with us for technical support.

- ✓ Website: [www.thermoeeye.co.kr](http://www.thermoeeye.co.kr)
- ✓ E-mail: [help@thermoeeye.co.kr](mailto:help@thermoeeye.co.kr)
- ✓ Tel: +82-70-4489-6196
- ✓ Head Office: 307, Research Building 3, 70, Yuseong-daero 1689 beon-gil, Yuseong-gu, Daejeon, Republic of Korea
- ✓ Seoul R&D: 4~5F, 169 Sadang-ro, Dongjak-gu, Seoul, Republic of Korea

Please visit the Thermoeeye Github to download detailed product manuals and SDK for application development.

- ✓ <https://github.com/thermoeeye/tmsdk>

## 8. Glossary

| Term     | Definition  |
|----------|---|
| CDC ACM  | USB Communication Device Class - Abstract Control Model |
| COM port | USB serial COMmunication port                           |
| DHCP     | Dynamic Host Configuration Protocol                     |
| DNS      | Domain Name System                                      |
| FOV      | Field Of View   |
| IP       | Internet Protocol                                       |
| LED      | Light-Emitting Diode                                    |
| MAC      | Media Access Control                                    |
| NEDT     | Noise Equivalent Differential Temperature               |
| NETD     | Noise Equivalent Temperature Difference                 |
| PoE      | Power over Ethernet                                     |
| ROI      | Region Of Interest                                      |
| RTSP     | Real-Time Streaming Protocol                            |
| RTP      | Real-time Transport Protocol                            |
| TCP      | Transmission Control Protocol                           |
| UDP      | User Datagram Protocol                                  |
| USB      | Universal Serial Bus                                    |
| USB-HS   | USB High Speed  |
| UVC      | USB Video device Class                                  |
| VOx      | Vanadium Oxide  |